

27.12.2023 // FabAccess FAQ

FabAccess Tasmota Actor konfigurieren

Actor verfügbar machen

```
git clone https://gitlab.com/fabinfra/fabaccess/actors/tasmota.git adapters/tasmota
chmod +x adapters/tasmota/main.py
```

Actor in bffh.dhall konfigurieren

```
actors =
{
  tasmota_F0A4FB =
  {
    module = "Process",
    params =
    {
      cmd = "/usr/local/lib/bffh/adapters/tasmota/main.py",
      args = "--host mqtt --tasmota F0A4FB"
    }
  }
},
```

Noua A1T / Tasmota konfigurieren

<https://tasmota.github.io/docs/Commands/>

PowerOnState auf 0 setzen, um eine Art Wiederanlaufschutz zu haben

PowerOnState Control power state when the device is powered up. More information
0 / OFF = keep power(s) OFF after power up
1 / ON = turn power(s) ON after power up

2 / TOGGLE = toggle power(s) from last saved state
3 = switch power(s) to their last saved state (default)
4 = turn power(s) ON and disable further power control
5 = after a PulseTime period turn power(s) ON (acts as inverted PulseTime mode)

Ggf. FriendlyName auf etwas lesbares ändern

!! Fuktioniert das noch mit dem Tasmota Actor? !!

“ FriendlyName<x> 1 = Reset friendly name to firmware default
<value> = set friendly name (32 char limit)

Tasmota aktualisieren

“ Upgrade 1 = download firmware from OtaUrl and restart
2 = (ESP32 only) download safeboot firmware based on OtaUrl and restart into safeboot
<value> = download firmware from OtaUrl if <value> is higher than device version

Webserver ausschalten und konfiguration nur über MQTT machen

!! Ist dann noch ein separates Netzwerk erforderlich? !!

“ Webserver 0 = stop web server
1 = start web server in user mode
2 = start web server in admin mode

WiFi einrichten

SSID<x> <x> = 1...2

<value> = set AP<x> Wi-Fi SSID and restart

1 = reset AP<x> Wi-Fi SSID to firmware default (STA_SSID1 or STA_SSID2) and restart

SSIDs are limited to 32 characters. Do not use special characters or white spaces in the SSID

“ Password<x> <x> = 1...2

<value> = set AP<x> Wi-Fi password and restart

1 = reset AP<x> Wi-Fi password to firmware default (STA_PASS1 or STA_PASS2) and restart

Passwords are limited to 64 characters. Do not use special characters or white spaces in the password.

Note that Password and Password1 are equivalent commands.

MQTT einrichten

“ MqttHost 0 = clear MQTT host field and allow mDNS to find MQTT host

1 = reset MQTT host to firmware default (MQTT_HOST) and restart

<value> = set MQTT host and restart (do NOT use .local)

“ MqttUser 0 = clear MQTT user name

1 = reset MQTT user name to firmware default (MQTT_USER) and restart

<value> = set MQTT user name and restart

“ MqttPassword 0 = clear MQTT password

1 = reset MQTT password to firmware default (MQTT_PASS) and restart

<value> = set MQTT password and restart (min 5 chars)

```
MqttPort 1 = reset MQTT port to firmware default (MQTT_PORT) and
restart
<value> = set MQTT port between 2 and 32766 and restart
```

MQTT mit TLS

mosquitto mit traefik einrichten

<https://medium.com/@synoniem/running-mosquitto-mqtt-server-with-docker-traefik-and-lets-encrypt-a1f6cbb864cc>

ggf. noch mit crowdsec absichern

<https://goneuland.de/traefik-v2-3-reverse-proxy-mit-crowdsec-im-stack-einrichten/>

ESP8266 unterstützen kein TLS mit Tasmota und muss selbst gebaut werden

<https://tasmota.github.io/docs/TLS/#compiling-tls-for-esp8266>

!! Durch FabInfra bereitstellen, damit neue Nous per OTA geflashes werden können? !!

platform.ini

```
certificates ; uncomment the following to enable TLS with 4096 RSA
-DUSE_4K_RSA
```

platformio_tasmota_env.ini

```
lib_extra_dirs =
                ${common.lib_extra_dirs}
                lib/lib_ssl
```

tasmota/user_config_override.h

```
#ifndef _USER_CONFIG_OVERRIDE_H_
#define _USER_CONFIG_OVERRIDE_H_
```

```
#ifndef USE_MQTT_TLS
#define USE_MQTT_TLS // Use TLS for MQTT connection (+34.5k code,
+7.0k mem and +4.8k additional during connection handshake)
#define MQTT_TLS_ENABLED true // [SetOption103] Enable TLS mode (requires
TLS version)
#define USE_MQTT_TLS_CA_CERT // Force full CA validation instead of
fingerprints, slower, but simpler to use. (+2.2k code, +1.9k mem during connection handshake)
// This includes the LetsEncrypt CA in
tasmota_ca.ino for verifying server certificates
// #define USE_MQTT_TLS_FORCE_EC_CIPHER // Force Elliptic Curve cipher (higher
security) required by some servers (automatically enabled with USE_MQTT_AWS_IOT) (+11.4k code,
+0.4k mem)
#endif

#endif // _USER_CONFIG_OVERRIDE_H_
```

Backup / Restore einrichten

Hardware empfehlung

Automatisches Deployment via Ansible?

Hilfsmittel

Links

<https://gitlab.com/fabinfra/fabaccess/dockercompose>

https://fab-access.readthedocs.io/en/v0.3/installation/server_docker.html

MQTT Explorer

<https://mqtt-explorer.com/>

Version #1

Erstellt: 2024-10-14 16:09:13 CEST von Mario Voigt (Stadtfabrikanten e.V.)

Zuletzt aktualisiert: 2025-02-25 21:22:13 CET von Mario Voigt (Stadtfabrikanten e.V.)